

あうるすぽっと

DMX対応表

DMX No	負荷回路	フェーダーNo.
1	FCシモ	1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
10		10
11		11
12		12
13		13
14		14
15		15
16	FCカミ	1
17		2
18		3
19		4
20		5
21		6
22		7
23		8
24		9
25		10
26		11
27		12
28		13
29		14
30		15
31	FCオク	1
32		2
33		3
34		4
35		5
36		6
37		7
38		8
39		9
40		10
41		11
42		12

DMX No	負荷回路	フェーダーNo.
43	1S	1
44		2
45		3
46		4
47		5
48		6
49		7
50		8
51		9
52		10
53		11
54		12
55		13
56		14
57		15
58	16	
59	17	
60	18	
61	19	
62	20	
63	2S	1
64		2
65		3
66		4
67		5
68		6
69		7
70		8
71		9
72		10
73	11	
74	12	
75	13	
76	14	
77	15	
78	16	
79	17	
80	18	
81	19	
82	20	
83	3S	1
84		2

DMX No	負荷回路	フェーダーNo.
85	3S	3
86		4
87		5
88		6
89		7
90		8
91		9
92		10
93		11
94		12
95		13
96		14
97		15
98		16
99		17
100	18	
101	19	
102	20	
103	UHシモ	1
104		2
105		3
106		4
107	UHカミ	1
108		2
109		3
110		4
111	PS	1
112		2
113		3
114		4
115		5
116		6
117		7
118		8
119		9
120		10
121	PSC	1
122		2
123		3
124		4

DMX No	負荷回路	フェーダーNo.
125	PSC	5
126		6
127		7
128		8
129		9
130		10
131		11
132		12
133		13
134		14
135		15
136		16
137		17
138		18
139		19
140	20	
141	1CL	1
142		2
143		3
144		4
145		5
146		6
147		7
148		8
149		9
150		10
151		11
152		12
153	2CL	1
154		2
155		3
156		4
157		5
158		6
159		7
160		8
161		9
162		10
163		11
164		12
165	FRSシモ	1

DMX No	負荷回路	フェーダーNo.
166	FRSシモ	2
167		3
168		4
169		5
170		6
171		7
172		8
173		FRSカミ
174	2	
175	3	
176	4	
177	5	
178	6	
179	7	
180	8	
181	FCシモ	L1
182	FCカミ	L2
183	1S	L3
184	1S	L4
185	2S	L5
186	2S	L6
187	3S	L7
188	3S	L8
189	PS	L9
190	PS	L10
191	PSC	L11
192	PSC	L12
193	1CL	L13
194	2CL	L14
195	FRSシモ	L15
196	FRSカミ	L16
197	客電	1
198		2
199		3
200		4
201		5
202		6
203		7
204	作業灯	後方軒下
205		

DMX No	負荷回路	フェーダーNo.
206	作業灯	
207		
210	FRSシモ (Pタイムスター)	
211		
212		
213		
214		
215		
216	FRSカミ (Pタイムスター)	
217		
218		
219		
220		
221		
222	1CL (Pタイムスター)	
223		
224		
225		
226		
227		
228	2CL (Pタイムスター)	
229		
230		
231		
232		
233		
234	BL (Pタイムスター)	
235		
236		
237		
238		
239		
240		
241		
242		
243		
244		
245		

※191～196はP.ディムスター電源として使用

※回路210～245は、P.ディムスターになります